

# PRODUCT DATA SHEET

## Sika Boom<sup>®</sup> Cleaner

### CLEANER FOR SIKA BOOM<sup>®</sup> APPLICATION GUNS

#### DESCRIPTION

Sika Boom<sup>®</sup> Cleaner is an active cleaner for cleaning Sika Boom<sup>®</sup> application guns and fresh Sika Boom<sup>®</sup> residue from surfaces.

#### USES

- Clean Sika<sup>®</sup> PU foam application equipment after use.
- Removes fresh, uncured polyurethane foam residue from equipment and other surfaces, as well as cleaning and removing grease from contaminated substrates.

#### CHARACTERISTICS / ADVANTAGES

- Very good PU foam cleaner
- Very good PU spray gun and equipment cleaner
- Integral valve for precise application

#### PRODUCT INFORMATION

<b>Composition</b>	Solvent-based cleaning agent
<b>Packaging</b>	500 ml pressurised container (can), 12 containers per box.
<b>Colour</b>	Transparent
<b>Shelf life</b>	18 months from the date of production. Must be used within 4 weeks.
<b>Storage conditions</b>	The product must be stored in original, unopened and undamaged sealed packaging in dry conditions at temperatures between +5 °C and +25 °C. Store in an upright position. Always refer to packaging.
<b>Density</b>	~0.70 kg/l

#### TECHNICAL INFORMATION

#### APPLICATION INFORMATION

**Ambient Air Temperature** +5 °C min. / +35 °C max.

## APPLICATION INSTRUCTIONS

### APPLICATION METHOD / TOOLS

Sika Boom® Cleaner with integral spray head can be used to clean the PU foam application valves and application gun parts or to remove residues and from substrates. Spray Sika Boom® Cleaner directly onto the fresh foam and allow it to react for 5 - 10 seconds, then wipe-off the residue with a clean cloth.

Sika Boom® Cleaner without integral spray head can be used to rinse PU foam application guns. First remove cured PU foam residues mechanically. Then screw the Sika Boom® Cleaner container (can) onto the dispenser gun and press the trigger a few times to flush out all PU foam residue. After this cleaning, the dispenser gun can be stored attached to the Sika Boom® Cleaner container. Before removing the dispenser gun from the Sika Boom® Cleaner container, repeat this process several times.

### IMPORTANT CONSIDERATIONS

- Sika Boom® Cleaner can partly dissolve or discolour sensitive substrates (e.g. varnish, paint, plastics, textiles). We recommend testing the compatibility and colourfastness discretely on an unobtrusive small area before use.
- Cured foam can only be removed mechanically.
- Do not open Sika Boom® Cleaner using excess force
- Do not incinerate Sika Boom® Cleaner container at any stage.
- Do not spray Sika Boom® Cleaner towards open flames or onto hot objects.
- Keep Sika Boom® Cleaner away from ignition sources and do not smoke when applying or close to Sika Boom® Cleaner.
- Sika Boom® Cleaner may form explosive mixtures without adequate ventilation.

## BASIS OF PRODUCT DATA

All technical data stated in this Product Data Sheet are based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

### LOCAL RESTRICTIONS

Please note that as a result of specific local regulations the declared data for this product may vary from country to country. Please consult the local Product Data Sheet for the exact product data.

### ECOLOGY, HEALTH AND SAFETY

For information and advice on the safe handling, storage and disposal of chemical products, users shall refer to the most recent Safety Data Sheet (SDS) containing physical, ecological, toxicological and other safety-related data.

### LEGAL NOTES

The information, and, in particular, the recommendations relating to the application and end-use of Sika products, are given in good faith based on Sika's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Sika's recommendations. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any written recommendations, or from any other advice offered. The user of the product must test the product's suitability for the intended application and purpose. Sika reserves the right to change the properties of its products. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request.

Sika Australia Pty Limited

ABN 12 001 342 329

aus.sika.com

Tel: 1300 22 33 48



Product Data Sheet  
Sika Boom® Cleaner  
July 2019, Version 02.01  
02051602000000015

SikaBoomCleaner-en-AU-(07-2019)-2-1.pdf